

MILITARY SPECIFICATION

ADAPTERS, CONNECTOR, COAXIAL, RADIO
FREQUENCY, (BETWEEN SERIES AND WITHIN SERIES)
GENERAL SPECIFICATION FOR

This supplement forms a part of Military
Specification MIL-A-55339, dated 1 July 1971.

SPECIFICATION SHEETS

- MIL-A-55339/1 - Adapter, Connector, Coaxial, Radio Frequency, In-Line, (Within Series BNC Jack to Series N Jack), Class 2.
- MIL-A-55339/2(USAF) - Adapter, Connector, Coaxial, Radio Frequency, (Series SMA), Class 2, Right Angle, Male to Female.
- MIL-A-55339/3 - Adapter, Connector, Coaxial, Radio Frequency, Right Angle, (Within Series N Plug to Series N Jack), Class 2.
- MIL-A-55339/4 - Adapter, Connector, Coaxial, Radio Frequency, In-Line, Jamnut Mounted, (Within Series N Jack to Series N Jack), (Hermetic and Non-Hermetic), Class 2.
- MIL-A-55339/5 - Adapter, Connector, Coaxial, Radio Frequency, (Within Series N), Class 2, Straight Plug.
- MIL-A-55339/6 - Adapter, Connector, Coaxial, Radio Frequency, (Within Series N), Class 2, "T" Plug.
- MIL-A-55339/7 - Adapter, Connector, Coaxial, Radio Frequency, (Within Series N), Class 2, Straight Plug.
- MIL-A-55339/8 - Adapter, Connector, Coaxial, Radio Frequency, In-Line, (Within Series C Jack to Series C Jack), Class 2.
- MIL-A-55339/9 - Adapter, Connector, Coaxial, Radio Frequency, (Within Series C), Class 2, Straight Plug.
- MIL-A-55339/10 - Adapter, Connector, Coaxial, Radio Frequency, (Within Series C), Class 2, Right Angle Plug.
- MIL-A-55339/11 - Adapter, Connector, Coaxial, Radio Frequency, (Within Series C), Class 2, "T" Plug.
- MIL-A-55339/12 - Adapter, Connector, Coaxial, Radio Frequency, In-Line, Jamnut Mounted, (Within Series C Jack to Series C Jack (Hermetic)), Class 2.
- MIL-A-55339/13 - Adapters, Connector, Coaxial, Radio Frequency, In-Line, Jamnut Mounted, (Within Series BNC Jack to Series BNC Jack, (Hermetic and Non-Hermetic)), Class 2.
- MIL-A-55339/14 - Adapter, Connector, Coaxial, Radio Frequency, Right Angle, (Within Series BNC Jack to Series BNC Plug), Class 2.
- MIL-A-55339/15 - Adapter, Connector, Coaxial, Radio Frequency, In-Line, (Within Series BNC Plug to Series BNC Plug), Class 2.
- MIL-A-55339/16 - Adapter, Connector, Coaxial, Radio Frequency, In-Line, (Within Series BNC Jack to Series BNC Jack), Class 2.
- MIL-A-55339/17 - Adapter, Connector, Coaxial, Radio Frequency, "T", (Within Series BNC Plug to 2 Series BNC Jacks), Class 2.
- MIL-A-55339/18 - Adapter, Connector, Coaxial, Radio Frequency, In-Line, (Between Series BNC Plug to Series N Plug), Class 2.
- MIL-A-55339/19 - Adapter, Connector, Coaxial, Radio Frequency, In-Line, (Between Series N Jack to Series C Plug), Class 2.
- MIL-A-55339/20 - Adapter, Connector, Coaxial, Radio Frequency, In-Line, (Between Series BNC Jack to Series N Plug), Class 2.
- MIL-A-55339/21 - Adapter, Connector, Coaxial, Radio Frequency, (Between Series C to Series N), Class 2, Straight Plug.
- MIL-A-55339/22 - Adapter, Connector, Coaxial, Radio Frequency, In-Line, (Between Series BNC Jack to Series C Plug), Class 2.
- MIL-A-55339/23 - Adapter, Connector, Coaxial, Radio Frequency, In-Line, (Between Series C Jack to Series BNC Plug), Class 2.
- MIL-A-55339/24 - Adapter, Connector, Coaxial, Radio Frequency, Flange Mounted, (Between Series BNC Plug to Series N Jack), Class 2.
- MIL-A-55339/25 - Adapter, Connector, Coaxial, Radio Frequency, In-Line, Jamnut Mounted, (Between Series BNC Jack to Series N Jack), Class 2.

MIL-A-55339A
SUPPLEMENT 1

- MIL-A-55339/26(USAF) - Adapter, Connector, Coaxial, Radio Frequency, (Between Series SMA to Series TNC), Class 2, Straight Plug.
- MIL-A-55339/27(USAF) - Adapter, Connector, Coaxial, Radio Frequency, (Between Series SMA to Series TNC), Class 2, Receptacle.
- MIL-A-55339/28 - Adapter, Connector, Coaxial, Radio Frequency, In-Line, Jamnut Mounted, (Within Series SMA Plug to Series SMA Plug (Hermetic)), Class 2.
- MIL-A-55339/29 - Adapter, Connector, Coaxial, Radio Frequency, In-Line, (Within Series SMA Plug to SMA Plug), Class 2.
- MIL-A-55339/30 - Adapter, Connector, Coaxial, Radio Frequency, "T", (Within Series SMA Plug to Two Series SMA Jacks), Class 2.
- MIL-A-55339/31 - Adapter, Connector, Coaxial, Radio Frequency, In-Line, (Within Series SMA Jack to Series SMA Jack), Class 2.
- MIL-A-55339/32 - Adapter, Connector, Coaxial, Radio Frequency, (Within Series TNC), Right Angle, Male to Female.
- MIL-A-55339/33 - Adapter, Connector, Coaxial, Radio Frequency, (Within Series TNC), Class 2, Straight Plug.
- MIL-A-55339/34 - Adapter, Connector, Coaxial, Radio Frequency, (Within Series TNC, (Hermetic)), Class 2, Receptacle.
- MIL-A-55339/35 - Adapter, Connector, Coaxial, Radio Frequency, (Within Series TNC), Class 2, "T" Plug.
- MIL-A-55339/36 - Adapter, Connector, Coaxial, Radio Frequency, (Within Series TNC), Class 2, Straight Plug.
- MIL-A-55339/37 - Adapter, Connector, Coaxial, Radio Frequency (Between Series BNC to Series TNC), Class 2, Straight Plug.
- MIL-A-55339/38 - Adapter, Connector, Coaxial, Radio Frequency (Between Series BNC to Series TNC), Class 2, Straight Plug.
- MIL-A-55339/39 - Adapter, Connector, Coaxial, Radio Frequency (Between Series BNC to Series TNC), Class 2, Straight Plug.
- MIL-A-55339/40 - Adapter, Connector, Coaxial, Radio Frequency, (Between Series SMA (Male) to Series TNC (Female)), Class 2, Straight Plug
- MIL-A-55339/41 - Adapter, Connector, Coaxial, Radio Frequency, (Between Series SMA (Female) to Series TNC (Female)), Class 2, Straight Plug.
- MIL-A-55339/42 - Adapter, Connector, Coaxial, Radio Frequency, (Between Series SMA (Female) to Series TNC (Male)), Class 2, Straight Plug.
- MIL-A-55339/43 - Adapter, Connector, Coaxial, Radio Frequency, (Between Series SMA (Male) to Series TNC (Male)), Class 2, Straight Plug.
- MIL-A-55339/44 - Adapter, Connector, Coaxial, Radio Frequency, In-Line, (Between Series SMA Jack to Series BNC Plug), Class 2.
- MIL-A-55339/45 - Adapter, Connector, Coaxial, Radio Frequency, In-Line, (Between Series SMA Plug to Series BNC Plug), Class 2.
- MIL-A-55339/46 - Adapter, Connector, Coaxial, Radio Frequency, In-Line, (Between Series SMA Jack to Series BNC Jack), Class 2.
- MIL-A-55339/47 - Adapter, Connector, Coaxial, Radio Frequency, In-Line, (Between Series SMA Plug to Series BNC Jack), Class 2.
- MIL-A-55339/48(USAF) - Adapter, Connector, Coaxial, Radio Frequency, (Between Series SMA to Series TNC), Class 2, Straight Plug.
- MIL-A-55339/49 - Adapter, Connector, Coaxial, Radio Frequency, (Between Series N Jack to Series BNC Plug).
- MIL-A-55339/50 - Adapter, Connector, Coaxial, Radio Frequency, (Within Series TNC Jack to Two Series TNC Jacks), Class 2, "T" Jamnut Mount.
- MIL-A-55339/51(USAF) - Adapter, Connector, Coaxial, Radio Frequency, (Between Series TNC to Series N), Class 2, Straight Plug.

